

Justrite 899020 90-gallon Self-Closing Flammable Storage Cabinet



Capacity: 90 gallons (341 liters)

Rating: Not Rated Yet

Price

Sales price \$975.00

[Ask a question about this product](#)

Description

The Justrite 899020 cabinet is a heavy-duty, code-compliant safety cabinet for storing up to 90 gallons of flammable liquids. Built with double-wall, 18-gauge welded steel and 1.5 in of insulating air space, it offers excellent fire resistance. The cabinet features self-closing doors that automatically latch when fusible links melt at 165 °F (74 °C). Inside, two SpillSlope™ shelves direct spills toward a 2-inch leak-proof sump. Additional safety features include dual vents with flame arresters, a grounding connector, reflective Haz-Alert™ labels, and a U-Loc handle that can accept a padlock.

Specifications

Miscellaneous: Justrite 899020 90-gallon Self-Closing Flammable Storage Cabinet

Capacity: 90 gallons (341 liters)

Construction: 18-gauge double-wall welded steel with 1.5 in (38 mm) insulating air space

Dimensions: Exterior: 65 in (H) x 43 in (W) x 34 in (D)

Doors / Latch: Two self-closing doors; three-point stainless steel bullet-latching system; fusible links melt at 165°F (74°C) to trigger closure

Shelves & Spill Control: Two adjustable galvanized SpillSlope™ shelves (on 3 in / 76 mm centers), leading to a 2 in (51 mm) leak-proof bottom sump

Extras: Dual vents with flame arresters, grounding connector, four leveling feet, U-Loc handle with key or optional padlock, Haz-Alert™ reflective labels

Comes with our 90-day warranty.

Biotech Equipment Sales, Inc.: based in South San Francisco, the Biotech capital of the world, since 2009. We are dedicated to bringing high-quality pre-owned laboratory instrumentation to our scientific community.

Biotech Equipment Sales, Inc.
226 Miller Ave.
South San Francisco, CA 94080
650-871-5707 office
650-276-7487 fax

sales@biotechequipmentsales.com