

U-Line H-15655-Y 60-gallon Self-Closing Flammable Storage Cabinet



Self-closing; 60 gallon capacity

Rating: Not Rated Yet

Price

Sales price \$650.00

[Ask a question about this product](#)

Description

This U-Line flammable storage cabinet is designed to securely store up to 60 gallons of flammable liquids. Built from rugged, double-wall 18-gauge steel, it offers reliable fire resistance and spillage containment. Its self-closing doors automatically shut if the temperature rises to around 165 °F (74 °C), helping to contain vapors and reduce fire risk. Adjustable, sloped galvanized shelves channel any leaks or spills into the base sump, while a three-point locking system and safety labeling enhance security and compliance.

Specifications

Construction: Double-wall 18-gauge steel for added fire resistance

Capacity: 60 gallons (227 liters)

Shelf Load & Design: Two adjustable shelves rated for up to 350 lb; shelves are sloped to direct spills safely toward the sump

Automatic Self-Closing Doors: Doors automatically close when cabinet temperature reaches 165°F. Bid on Equipment

Safety & Compliance: Meets NFPA 30, OSHA 29 CFR 1910, and IFC standards; includes three-point locking (with 2 keys), continuous piano hinge, dual vents with flame arrestors, and an 8.3-gallon leak-proof sump

Outside dimensions (W x D x H): 34 in x 34 in x 65 in

Inside dimensions (W x D x H): 30.8 in x 30.8 in x 61.1 in

Shelf size (actual) per shelf: 30 3/8 in x 29 in (W x D)

Comes with our 90-day warranty.

Biotech Equipment Sales, Inc.: based in South San Francisco, the Biotech capital of the world, since 2009. We are dedicated to bringing high-quality pre-owned laboratory instrumentation to our scientific community.

Biotech Equipment Sales, Inc.
226 Miller Ave.
South San Francisco, CA 94080
650-871-5707 office
650-276-7487 fax
sales@biotechequipmentsales.com